CABINET PARTS

REFRIGERATOR

Whirlpool

For Models: ET4WSKXKQ00, ET4WSKXKZ00, ET4WSKXKT00
ET4WSKYKQ00, ET4WSKYKZ00, ET4WSKYKT00
(White) (Almond) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: ET4WSKXKQ00, ET4WSKXKZ00, ET4WSKXKT00
ET4WSKYKQ00, ET4WSKYKZ00, ET4WSKYKT00
(White) (Almond) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT2210096	Service & Wiring Sheet
	LIT2217627	Energy Label
	LIT2210108	Use & Care Guide

Following May Be Purchased

DO−IT−YOURSELF REPAIR MANUALS

	LIT677969	Do−It−Yourself Manual Ref./Fzr.
2	2189410	Hinge (Top)
3	2217757	Roller−Front
4	487576	Washer−Nylon
5		Cabinet (Not A (Serviceable Part)
9	2201556	Screw
12	549193	Clamp−Cord
15	489497	Screw
16	2166086	Hinge, Center
17	2166043	Shim, Hinge Center
20	2166094	Hinge Butt
21	9791682	Hinge−Pin Bott.
22	3428970	Screw
23	2201567	Shim, Bottom Hinge
24	2174760	Fitting, Water Tube
25	489497	Screw
27		Hole Plug (6)
	2201012	White
	2201013	Almond
	2200924	Biscuit
30	1106508	Seal
32	489498	Screw
33	489084	Screw, 8 x 1/2 A
35		Corner Filler
	2166003	White
	2166004	Almond
	2202282	Biscuit
37	487996	Cap Bushing
38	487802	Washer

DOOR PARTS

For Models: ET4WSKXKQ00, ET4WSKXKZ00, ET4WSKXKT00
ET4WSKYKQ00, ET4WSKYKZ00, ET4WSKYKT00
(White) (Almond) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: ET4WSKXKQ00, ET4WSKXKZ00, ET4WSKXKT00
ET4WSKYKQ00, ET4WSKYKZ00, ET4WSKYKT00
(White) (Almond) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door Panel (Also Order Item 11)
	2201546	White
	2201547	Almond
	2215347	Biscuit
3	8281206	Screw
5		Handle Center
	2202807W	White Model
	2202807N	Almond Model
	2202807T	Biscuit
6	489357	Screw
8	8281146	Screw
9	2191888	Door Gasket, Magnetic
10	489442	Screw
11	876029	Foam Insulation (Required When Replacing Exterior Door Panel)
12		Cover, Screw
	2202819W	White Model
	2202819N	Almond Model
	2202819T	Biscuit
13		Nameplate
	2157907	White
	2183209	Almond
	2213233	Biscuit
14	939101	Screw Anchor
15	2173725	Interior Door Panel (Refrigerator)
16	2163630	Trim, Door Shelf (Upper)
17	2183003	Thimble
18	2163631	Trim, Door (Middle)
19		Freezer Door Panel (Also Order Item 11)
	2201544	White
	2201545	Almond
	2215350	Biscuit
20		Hole Plug
	2189000	White
	2189008	Almond
	2200936	Biscuit
21	1122551	Retainer, Gasket
22	1120614	Retainer, Gasket
23	2191889	Door Gasket, Magnetic
24	9790358	Interior Door Panel (Freezer)
25	2163628	Trim, Door Shelf (Lower)
26	2217944	Bracket, Door Stop
27	488921	Screw
28		Hole Plug
	2212648	White
	2213324	Almond
	2212649	Biscuit
29	2156007	Plug−Trim
30	2156006	Plug−Trim
31	2163372	Hole Plug
32	2183198	Tap Plate
33		Handle, F.C.
	2202098	White Model
	2202099	Almond Model
	2215015	Biscuit
34	1122553	Retainer, Gasket
37	2163629	Trim−Door (2)

LINER PARTS

For Models: ET4WSKXKQ00, ET4WSKXKZ00, ET4WSKXKT00
ET4WSKYKQ00, ET4WSKYKZ00, ET4WSKYKT00
(White) (Almond) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LINER PARTS

For Models: ET4WSKXKQ00, ET4WSKXKZ00, ET4WSKXKT00
ET4WSKYKQ00, ET4WSKYKZ00, ET4WSKYKT00
(White) (Almond) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	939962	Rivet−Plastic
3	2183061	Cover, Air Diffuser
4	2188371	Timer, Defrost
5	489174	Screw
6	941839	Hole Plug
7	2176927	Wire Assembly Control Box
8	2162085	Socket, Light
9	2197404	Fan Support Bracket
10	2197405	Fan Mounting Bracket
11	2169141	Fan Blade
12	2215213	Control Box
13	2183403	Thermostat
14	488693	Screw
15	1118680	Thermostat Tube Barrier
16	2201205	Cover−Evaporator
17	527949	Light Bulb
18	9791702	Light Shield
19	1118894	Rocker Arm Switch
20	489438	Screw
21	2192096	Wiring−Freezer
22	2202885	Control Knob
23	9790408	Air Tower
24	2197052	Hood And Foil Assembly
25	2174798	Freezer Floor
26	2197030	Air Diffuser
27	2190688	Cover, Hole
28	2197380	Grommet−Motor
29	489478	Screw
30	2221893	Evaporator Fan Motor
31	489115	Fastener−Snap In
32	489442	Screw
34	489474	Screw
35	2197416	Deflector, Air

UNIT PARTS

For Models: ET4WSKXKQ00, ET4WSKXKZ00, ET4WSKXKT00
ET4WSKYKQ00, ET4WSKYKZ00, ET4WSKYKT00
(White) (Almond) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: ET4WSKXKQ00, ET4WSKXKZ00, ET4WSKXKT00
ET4WSKYKQ00, ET4WSKYKZ00, ET4WSKYKT00
(White) (Almond) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	2175260	Support Plate, Compressor
2	944772	Bumper
3	2192693	Condenser
4	2176942	Heater, Defrost
5	487415	Screw
6	489442	Screw
7	2201515	Heat Shield
9	2174706	Clip, Roller
10	488725	Screw
12		Cover
	2162358	Production
	4387731	Service
13		Overload
	2214067	Production
	4387766	Service (Includes Relay)
14		Grommet
	2163786	Production
	4387558	Service
15		Start Relay
	2213763	Production (Service See Overload)
16	939054	Clip, Wire
17	2150304	Roller
18	2179826	Axle, Rivet
19	2166053	Wedge−Evaporator
20	2166055	Evaporator Assy.
21	9791833	Clip, Evaporator Tube
23	2166054	Wedge−Evaporator
24	489153	Hex Nut
25	2172892	Clip, Condenser Mounting
26	2213986	Bracket, Condenser
28	2216049	Compressor (Includes Items 12, 13, 14, 15, 29, 32, 33 & 38) (Also Order 482801 Installation Kit & 876765 Tube Kit)
29		Drier
	2201796	Production
	4387019	Service
30	2155774	Strap
32		Capacitator
	999532	Production
	4387764	Service
33	488687	Screw
35	1105406	Tube Clip
37	24364001	Clip, Compressor
38	2172890	Wire Assembly, Capacitator
42	2165793	Wire Assy. Unit
43	2201801	Evap. Tray
44	2174791	Tube, Discharge
45	2174739	Tube, Process

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE

3.75 Ozs.
(R134A)

SHELF PARTS

For Models: ET4WSKXKQ00, ET4WSKXKZ00, ET4WSKXKT00
ET4WSKYKQ00, ET4WSKYKZ00, ET4WSKYKT00
(White) (Almond) (Biscuit)

FREEZER



Illus. No.	Part No.	DESCRIPTION
1	2201793	Ice Tray (2)
2	2192515	Shelf (2)
3	9791659	Glass Cover
4	2208098	Crisper Pan
5	2174797	Shelf, Ice Tray

REFRIGERATOR



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: ET4WSKXKQ00, ET4WSKXKZ00, ET4WSKXKT00
ET4WSKYKQ00, ET4WSKYKZ00, ET4WSKYKT00
(White) (Almond) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
		Parts Not Illustrated and Optional Parts (Not Included)
	978941	Insulation, Fiberglass (63−1/2" x 35−1/2" x 2−5/8")
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4" x 108")
	876305	Kit, Insulation (14 Pcs. 3" x 24" x 48")
	876370	Kit, Insulation (2 Pcs. 3" x 24 " x 48")
	876029	Kit, Foam Slab (30" x 32−1/2" x 1−1/2")
	505587	Sealer, Mastic (1 Qt.)
	511873	Touch−Up, White Porcelain (2 Oz.)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1−1/4 Oz.)
	606755	Bag, Insulation (36−5/8" x 46")
	799833	Kit, Evaporator Repair (Aluminum Epoxy)
	799832	Kit, Porcelain Repair (White)
	503695	Cork Sealer (1/4 Pound)

Illus. No.	Part No.	DESCRIPTION
		Customer Touch−Up Material
	*350942	Primer, White (13 Oz. Spray Can)
	*350939	Enamel, Black (13 Oz. Spray Can)
	*350930	Enamel, White (13 Oz. Spray Can)
	*350956	Enamel, Almond (13 Oz. Spray Can)
	72017	Brush Touch−Up Kit (White)
	72032	Brush Touch−Up Kit (Black)
	72107	Brush Touch−Up Kit (Almond)
		Refinishing Material
	799344	Enamel, White (1 Qt. Uncut)
	978883	Enamel, Almond (1 Qt. Uncut)
	833938	Kit, Terminal Connector

*__Caution:__ The spray paint is not to be used where the paint may make contact with the door gaskets.

ICE MAKER FIELD INSTALLABLE

2155469	ECKMF94

TORX SCREW WRENCH

1117510	Torx Key